

Step 1

Click on the Quick Settings Panel at the bottom right of your screen.




Step 2

Click on "no-network."



Step 3

Select your Wifi Network.



Step 4

Pick one and enter the password if it calls for one.

